


sink battery installation



BATTERY SAFETY INFORMATION:
 ⚠️ **WARNING!** Battery acid leakage can cause personal injury and cause damage to the product and surrounding property. If battery leakage occurs, thoroughly wash any affected skin, making sure to keep battery acid away from eyes, ears, nose and mouth. If battery acid gets into your eyes, flush with clean water for 15 minutes. Do not use leaking battery acid. Leaking batteries may make "popping" sounds. Always remove replaceable batteries before disposing product. Dispose batteries or products with non-replaceable batteries according to Local, State or Federal Battery and Recycling Laws.

TO AVOID BATTERY PROBLEMS:
 • NEVER mix old and new batteries or different brands of batteries.
 • NEVER mix alkaline, standard (carbon-zinc), rechargeable batteries with this product.
 • NEVER dispose of batteries in the fire, as they may leak and explode.
 • ALWAYS have an adult install batteries consistent with installation instructions.
 • ONLY use batteries specified by manufacturer.
 • Batteries are to be inserted with the correct polarity (+ and -).
 • Non-rechargeable batteries are not to be recharged.
 • Rechargeable batteries are to be removed from the toy before being charged.
 • Rechargeable batteries are only to be charged under adult supervision.

⚠️ **WARNING: ADULT ASSEMBLY AND SUPERVISION REQUIRED.**
 ⚠️ **ATTENTION : MONTAGE ET SURVEILLANCE DEVANT ÊTRE CONFIES À UN ADULTE.**
IMPORTANT SAFETY INFORMATION:
 • ADULT ASSEMBLY REQUIRED.
 • UNPACK, ASSEMBLE AND SET UP PRODUCT CAREFULLY.
 • ALWAYS ASSEMBLE PARTS/SECTIONS UNATTENDED DUE TO POTENTIAL HAZARDS.
 • NEVER USE PRODUCT UNLESS IT CAN BE PROPERLY ASSEMBLED.
 • REMOVE ALL PACKAGING ATTACHMENTS BEFORE GIVING PRODUCT TO CHILD.
 • ALWAYS ENSURE PRODUCT IS SECURELY LOCKED IN PLACE BEFORE USE.




©2021 and manufactured for / fabriqué pour JAKKS PACIFIC, INC. 2051 28TH ST. SANTA MONICA, CA 90405 USA
 © and/or™ designate U.S. trademarks of / désignent les marques déposées aux États-Unis de JAKKS Pacific.
 Other trademarks used under license / Autres marques déposées utilisées sous licence.
MADE IN CHINA. FABRIQUÉ EN CHINE.
 Imported into UK by / Importé au Royaume-Uni par JAKKS Pacific (UK) Ltd., 1 Affington Square, Downshire Way, Bracknell, Berkshire RG12 1WA, GB, and EU by / et UE par JAKKS Europe B.V., Herkenbergweg 88, 1101 CM Amsterdam NL.
 www.jakks.com www.jakks.com/warranty consumers@jakks.com
 North America / Amérique du Nord: 1.877.875.2557 or 1.909.594.7771
 UK & EU / Royaume-Uni et UE: 00.44(0)1344.638909
 Colors & decoration may vary. Retain packaging/instructions for reference. / Les couleurs et la décoration peuvent varier par rapport aux illustrations. Conserver l'emballage/instructions pour toute référence.
 Remove all packaging before giving toy to child. / Enlever le paquet de l'emballage avant de le donner à un enfant.

PERFECTLY CÛTE

ages 2+

instruction guide




PRETEND • PLAY
Magic Sink Set
 Item #71213

⚠️ **WARNING:**
 ADULT ASSEMBLY AND SUPERVISION REQUIRED.
 ⚠️ **ATTENTION :**
 MONTAGE ET SURVEILLANCE DEVANT ÊTRE CONFIES À UN ADULTE.

Prior to assembly, please read the Important Safety Information section on the back page.
 Please save your instruction sheet for future use.

parts list



sink assembly & use



1. Insert Utensil Rack into Sink Basin, then insert Faucet into Utensil Rack.



2. Fill room temperature water to the "2.0 L" line on the inside of the Sink Basin.

NOTE: Only use water in the Magic Sink, never use any other liquids. Do not overflow basin and make sure to protect nearby surfaces from water. Always supervise children when playing with water.



3. Pull lever forward to turn Faucet ON. Rotate lever back to OFF position when finished playing. Make sure the Faucet and other toy parts are empty and dry before storing.